






Cup wiping machine
Instruction for use

1: Appearance size



-1-

2:Product use

1. This product is called Wipe cup machine,
It can be polished and dried on the surface of the cup,
Dry 25 cups in one minute,
The place of use is buffet, bar and canteen.

3:Product parameters

Name	Model number	Net weight	Product size	Package size	Voltage/Frequency	Power	Exhaust outlet
Five heads Cup wiping machine	MLP-5T	14kg	330*330*H500	445*405*H415	220V/50Hz	1200W	single

4:Installation requirements

1. Must meet the product voltage requirements before use;
2. The power outlet must be equipped with a ground cable ;
3. This product noise, as far as possible away from the environment requires a quiet area;
4. The product is heavy and requires it to be placed on a solid table to run the operation;
5. Placement height requirements of 700mm, to prevent children from touching.

5:Matters needing attention

1. Water injection and blockage are strictly prohibited,
Touch the vent area;
2. Power off required for cleaning or maintenance,
It is strictly prohibited to remove the exhaust pipe;
3. Vents, when the limit temperature is reached or clogged,
Stop heating, resume in 1 minute;
4. When there is no ground in the power outlet,
It is strictly prohibited to use electricity;
5. Can only be operated by a single cup;
6. When no one is operating after power, please turn off the power supply ;
7. If there is an anomaly, it is strictly prohibited to disassemble the machine,
Personnel should be notified of maintenance.

-2-

6: Method of operation

1. Plug the power cord into the appropriate outlet and press the on / Off button indicator, The indicator is always red;
2. Press the 0 sign to enter the standby state, the brush head stops rotating, Exhaust port to stop blowing hot air;
3. Press the I symbol to enter the working state, brush head rotation, Exhaust port normal hot air blowing;
4. Brush head is divided into 5, the cup is placed vertically, insert the working brush head, For polishing and drying moisture;
5. The cup is polished and dried for 6 seconds at a time for best results;



7: Cleaning and maintenance

1. Only after a power outage. Cleaning and maintenance;
2. Water jet cleaning is strictly prohibited;
3. Removable brush for cleaning, do not scrub hard, To prevent the fiber thread from falling off;
4. Scrub the surface with a wet towel or cleaning fluid;

WARNING:


This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

8: Electrical schematic



A: Insurance tube
C: Heating wire
E: Centrifugal fan
G: Motor

B: Main switch
D: Temperature switch
F: Capacitance